



ResponseCard IR Device ID Programming (Optional)

Set and identify ResponseCard Device IDs. Identify ResponseCards in a logical order - record them in participant lists for more customized data management.



Programmable ID:

- 1) Press and hold the ***** and **6/F** buttons simultaneously for 3 seconds. The LED will turn red.
- 2) Enter up to a 3 digit number you would like to program. Wait for the LED to flash after each digit is entered.
- 3) Press the ***** button and the LED will flash 3 times to indicate that the ResponseCard was successfully programmed.

Reverting to Factory Setting Fixed ID:

- 1) Press and hold the ***** and **1/A** buttons simultaneously for 3 seconds. The LED will turn red.
- 2) Release both buttons. The LED will flash 3 times to indicate that the ResponseCard was successfully programmed.